

GUIDELINES FOR THE ON-SITE ASSESSMENT OF HISTORIC TIMBER STRUCTURES

Short title: **Guidelines for the assessment of timber structures**

Helena Cruz(1), David Yeomans(2), Eleftheria Tsakanika(3), Nicola Macchioni(4),
Andre Jorissen(5), Manuel Touza(6), Massimo Mannucci(7), Paulo B. Lourenço(8)

1 – PhD, Senior Research Officer, Laboratório Nacional de Engenharia Civil (LNEC), Avenida do Brasil, 101. 1700-066 Lisboa. Portugal. Telef: +351218443295; Fax: -351218443025; helenacruz@lnec.pt

2 – PhD, Consultant, 7 Moon Gorove, Manchester, M14 5HE, UK. Tel/Fax, 441612254175; mail@davidyeomans.co.uk

3 – PhD, Lecturer, National Technical University of Athens, School of Architecture, Laboratory of Building Materials, 5 Heroon Polytechniou Str, Zografou Campus, Athens, Greece. Tel: +306972880385, +302107721394; Fax : +302106890146; eletsaka@central.ntua.gr

4 – PhD, Researcher at CNR – IVALSA Via Madonna del Piano, 10 50019 Sesto Fiorentino, Italy , tel.+390555225502, fax +390555225507 macchioni@ivalsa.cnr.it

5 – PhD, Responsible for education and research related to timber structures at Eindhoven University of Technology (TU/e) and Senior Research Officer at SHR, Nieuwe Kanaal 9^b, 6709 PA Wageningen, The Netherlands. Telef: +31 317467366; Fax: +31 317467399; a.jorissen@shr.nl

6 – PhD, Head of R&D, Centro de Innovación y Servicios Tecnológicos de la Madera de Galicia (CIS-Madeira), Avenida de Galicia, 5. Parque Tecnológico de Galicia. San Cibrao das Viñas. 32901 Ourense. España. Telef: +34988368152; Fax: +34988368153; manuel.touza@cismadeira.com

7 – PhD, LegnoDOC srl, Via Borgo Valsugana 11 - 59100 Prato (PO) Italy, Tel.+39 0574 36953, Fax +39 0574 404677, massimo.mannucci@legnodoc.com

8 – PhD, Professor, ISE, University of Minho, Department of Civil Engineering, Azurém. 4800-058 Guimarães. Portugal. Phone: +351 253 510 209, fax: +351 253 510 217, E-mail: pbl@civil.uminho.pt.

ABSTRACT

In the scope of COST IE0601-WoodCulther (<http://www.woodculther.org>) it was agreed to produce Guidelines for the Assessment of Historic Timber Structures, covering the principles and possible approaches for the safety assessment of old timber structures of historical relevance, that could be used as the basis for possible European Standards, as discussed with CEN/TC346 (Conservation of cultural heritage).

This was targeted at all those concerned with the conservation of heritage buildings. It should also help decision-making regarding the need for immediate safety measures. Its aim is to guarantee that inspection and assessment measures provide the necessary data for historical analysis, structural safety assessment and planning of intervention works, while having minimal impact on the building fabric (the original materials, structural systems and techniques).

This paper provides information on the criteria to be used in the assessment of load bearing timber structures in heritage buildings. It covers the preliminary assessment (desk survey, preliminary visual survey, measured survey, structural analysis and preliminary report), as well as the detailed survey of timbers (with a special emphasis on visual strength grading on site) and carpentry joints. The subsequent diagnostic report and the detailed design of repairs are outside its scope.

keywords: Assessment, Timber structures, Historic, Heritage, On-site, Strength grading, Carpentry joints

TABLE OF CONTENTS

FOREWORD

SCOPE AND FIELD OF APPLICATION

PART I – PRELIMINARY ASSESSMENT

- I. 1. INTRODUCTION
 - I. 1.1. Need for assessment
 - I. 1.2. Principles
 - I. 1.3. Time dependant results
 - I. 1.4. Necessary conditions for the inspection
- I. 2. DESK SURVEY – HISTORICAL RESEARCH AND ANALYSIS
- I. 3. PRELIMINARY VISUAL SURVEY
- I. 4. MEASURED SURVEY
 - I. 4.1. Geometrical survey
 - I. 4.2. Technological survey
 - I. 4.3. Damage survey
- I. 5. STRUCTURAL ANALYSIS
- I. 6. PRELIMINARY REPORT

PART II - DETAILED SURVEY OF TIMBERS

- II. 1. INTRODUCTION
- II. 2. IDENTIFICATION OF WOOD SPECIES
- II. 3. DETERMINATION OF WOOD MOISTURE CONTENT AND MOISTURE GRADIENTS
- II. 4. STRENGTH GRADING OF TIMBER
 - II. 4.1. Principles
 - II. 4.2. Basis of the strength grading of historic timbers and research needed
 - II. 4.3. Identification of structural member types
- II. 5. ON-SITE VISUAL STRENGTH GRADING OF STRUCTURAL TIMBER MEMBERS
- II. 6. STRENGTH ASSESSMENT USING NON-DESTRUCTIVE TECHNIQUES
- II. 7. CHARACTERIZATION OF BIOLOGICAL DAMAGE
 - II. 7.1. Identification of biological damage
 - II. 7.2. Assessment of residual cross section
 - II. 7.3. Assessment of residual density (or equivalent density loss)

PART III - DETAILED SURVEY OF TIMBER JOINTS

- III. 1. INTRODUCTION
- III. 2. DETAILED GEOMETRY
- III. 3. PATHOLOGY
- III. 4. TIMBER QUALITY AND CONDITIONS

FINAL REMARKS

ACKNOWLEDGEMENTS

DEFINITIONS

REFERENCES

BIBLIOGRAPHY

FOREWORD

This paper originates from a document with the same name discussed within the Task Group “Assessment of Timber Structures” set within COST Action IE0601 – Wood Science for Conservation of Cultural Heritage (<http://www.woodculther.org>), which could be used as the basis for possible European Standards, as discussed with CEN/TC346 (Conservation of cultural heritage).

This paper is targeted at all those concerned with the conservation of heritage buildings and covers the principles and possible approaches for the safety assessment of old timber structures of historical relevance.

SCOPE AND FIELD OF APPLICATIONA distinction needs to be made between heritage/historic structures and other existing structures even if many of the assessment methods are common to both. A greater value is placed on the fabric of the heritage structures because of their historical significance. This may justify greater expense both in the survey/diagnosis/assessment of the structure and in the repair methods that might be employed. Repair or strengthening work should only be carried out to a heritage structure as a last resort and then any intervention should be kept to a minimum. The best possible assessment of its existing structural characteristics must be made, which might require the use of more precise and sophisticated methods than are those used for other existing structures, with associated costs that could not otherwise be justified.

This document provides information on the criteria to be used in the assessment of load bearing timber structures in heritage buildings.

It is targeted at all those concerned with the conservation of heritage buildings which contain wooden elements, including the specialists employed and the building owners or authorities who are responsible for them. It should also help decision-making regarding the need for immediate safety measures. Its aim is to guarantee that inspection and assessment measures provide the necessary data for historical analysis, structural safety assessment and planning of intervention works, while having minimal impact on the building fabric (the original materials, structural systems and techniques).

Briefly, the steps required for the assessment of an historic timber structure and the planning and execution of any intervention are as follows (Figure 1):

- 1 A **desk survey**, which will deal with the history of the structure making clear its heritage value. This should also take into account the intentions of the building owner regarding its use and accepted alterations, so that the intended ultimate load and environmental conditions are clearly stated.
- 2 A **preliminary visual survey**. This is simply to obtain an overview of the structure that is sufficient to plan the next stage identifying what provisions need to be made to gain safe access to the timber structure.
- 3 A **measured survey** to determine the overall disposition of the structural members and locate the main problems. This survey should include principal dimensions and the nominal sizes of all members. It should also note any obvious signs of damage, decay or structural distress, which will need to be investigated in more detail at a subsequent stage.
- 4 A **structural analysis** to determine the overall forces and general levels of stress within the structure.
- 5 The preparation of a **preliminary report** which will specify any additional survey work that may be necessary. (One might need to do this simply to provide the client with a more accurate estimate of costs.) This will indicate

what aspects of the structure require further investigation and what methods are recommended. It will draw upon the four tasks already carried out, identify the aspects of the structure that need to be preserved for their heritage value, identify areas of high stress and/or significant biological attack that need further measurement, note any 'defects' within the structure and identify the vulnerable areas.

These items are dealt with in detail in **Part I**.

- 6 A ***detailed survey*** as indicated in the preliminary report. This will include the measurement of areas of biological attack and damage, the assessment of timber grades and the results of non-destructive methods where appropriate and will also consider the adequacy of joints. This is dealt with in detail in **Parts II and III**.
- 7 A ***diagnostic report*** on the condition of the structure and causes of distress with proposals for remedial measures where necessary. This may imply a new structural analysis considering the data gathered in the detailed survey.
- 8 A ***detailed design of repairs*** and maintenance in collaboration with other members of the team. Whenever possible, the carpenters/contractors should be included in this discussion. However, it is recognised that this is often impossible under public contracts and public tendering processes, meaning that future adjustments may be necessary for the execution of works and final preparation of execution drawings.

Proposals for remedial measures need to take into account the owner's intentions as indicated in item 1 but also to point out any areas of conflict between a) the need to preserve its heritage value b) the owner's intentions and c) the need for public safety.

Although the list above suggests a linear process it is essential to recognize that conservation frequently involves iterations. For example the preliminary visual survey might raise questions that could be answered by a more thorough desk survey, able to document changes that have been observed in the structure. Iterations between structural analysis and repair strategy stages are also often required.

A holistic approach is always required, considering and assessing the structure as a whole, rather than just the individual members and joints.

PART I – PRELIMINARY ASSESSMENT

I. 1. INTRODUCTION

I. 1.1. Need for assessment

One would normally assume that a structure that has proved to be adequate in the past will continue to be structurally adequate requiring no detailed assessment of timber strengths, although due consideration might still be needed regarding extreme events such as hurricanes, snow storms, earthquakes, fires or other.

However a structural assessment is certainly needed when:

- i) There is to be a change in use of the structure and hence a possible change in loads.

- ii) There has been significant decay or insect damage to the timbers, or the structure has suffered damage, e.g. due to fire.
- iii) There has been mechanical damage or excessive deflection indicating overloading of the timbers in the past, inferior initial design or poor quality of the used materials.
- iv) There have been alterations/interventions to the structure during its lifetime that have resulted in a reduction of its strength or changes to the original structural system.

It should be mentioned that there are occasional examples of poor initial design or workmanship. In such situations, or whenever past structural alterations or damage of timber and joints imply insufficient strength, measures must be taken to guarantee an adequate safety level and/or to limit public access.

I. 1.2. Principles

Within the scope of these guidelines, the assessment of any existing timber structure has to be performed by desk work (historic/architectural survey, structural analysis, etc), on site inspections and other complementary on site measurements and laboratory tests.

The general principle is that all inspections and surveys are non-destructive so that no part of the structure has to be removed or sampled except for small samples used for identification of timber species and biological decay agents. In any case the sampling should not modify the mechanical properties of the elements or have an impact on the other properties (e.g. aesthetical or historical) of the timber structure.

I. 1.3. Time dependant results

Note that the assessment results pertain to the moment of assessment since degradation is generally a continuing process and further deterioration must be anticipated until suitable remedial measures have been adopted and become effective.

This situation occurs in the presence of an active insect attack requiring intervention that may or may not have immediate results, or when high moisture content levels not only require solving the water intake source but also subsequent drying of timber and adjacent building materials before biological degradation can be curtailed.

I. 1.4. Necessary conditions for the inspection

The following conditions must be met (UNI 11119:2004):

Safety: the timber structure must provide reasonable safety level to walk on or walk under, otherwise propping or shoring is necessary;

Accessibility: the timber members must be made sufficiently accessible to allow for the assessment procedures to be carried out;

Access will depend upon the nature of the structure itself and may be as basic as simple ladder or may require full scaffolding. Accessibility has a great influence on the choice of the inspection technique.

Lighting: proper light (quality and intensity) must be used to permit a correct visual examination of the joints, the timber members as a whole and the wood surface details.

Note that some control over the lighting may be necessary since surface features are sometimes easier to see with appropriate directional lighting rather than bright general light.

Cleaning: the surface of the wood must not be covered or concealed in any way by debris, dirt and dust. The surveyor must be adequately equipped to clean areas of the timbers as required by using dry processes (brushing, vacuum cleaning, air pressure, etc.).

Note 1: In the case of decorated (painted) or covered timber members, wood surface accessibility and visibility may not be fully possible. In such cases, the inspection report must detail what information was not obtained and explain why.

Note 2: Inspection is particularly important in highly stressed points of the structure, particularly areas subjected to high bending moments, near joints and at the supports. In all parts of the structure where a regular visual inspection is not possible, such as the ends of beams inserted into supporting walls, alternative inspection methods, e.g. by resistance drilling methods, or indirect assessment techniques should be carefully planned.

I. 2. DESK SURVEY – HISTORICAL RESEARCH AND ANALYSIS

A desk survey is an integral part of any conservation process. Its purpose is to gather documents and other sources of information (e.g. drawings, photos, oral testimonies) relating to the structure, which will provide information on the historical aspects of the structure and any which relate to its present use and status as a heritage building. Any information regarding the loading conditions during its lifetime, previous interventions or restorations should be included.

In cases where the structure is mainly of timber, a timber structures specialist might well be taking the lead and so be responsible for the desk survey. In such cases it is important that the timber structures specialist is conversant with the history of the structural type and the possible location of historic documents.

I. 3. PRELIMINARY VISUAL SURVEY

A preliminary visual inspection is required to identify any obvious damage and susceptible zones of the structure, to determine the assessment strategy, and to identify the possible need for any immediate propping or stabilizing measures, and/or restriction of access (Figure 2). This work should be done by a specialist who understands timber structures.

The inspection should begin by looking at where problems are most likely to occur.

This preliminary survey is also required to evaluate the working conditions (accessibility, lighting and cleaning) and the safety conditions for the operators and related safety measures (for example to identify and circumscribe inaccessible areas because of risks of structural collapse, risk of falling, etc.).

I. 4. MEASURED SURVEY

This stage is the foundation for all that follows and must be carefully carried out and documented so that it can be drawn upon by other members of the conservation/restoration team. It must comprise geometrical, diagnostic and technological aspects.

I. 4.1. Geometrical survey

This should comprise:

- A drawn survey of the structure, fully dimensioned (this survey should also include non-structural members and note possible interactions with other structures). In some cases the usual 2-dimensional drawings have to be completed by 3-dimensional axonometric sketches and drawings of construction details (Figures 3, 4 and 5);
- The typical dimensions and shape (when necessary) of all timbers;
- A note of the method of conversion identifying sawn faces and axe hewn or adzed faces;
- A note of joint types, materials and typical dimensions where these could be clearly seen;
- Where it is the timber structure that is of historic significance (such as in medieval timber framed buildings) the survey should in addition include a dimensioned drawing of all significant structural timbers, noting features such as tool marks and marks made by the carpenters in setting out the framing.

I. 4.2. Technological survey

This should comprise:

Identification of wood species. Initially this may be conducted through a quick visual inspection, at least placing the timbers within a clear group, if only to distinguish between softwood and hardwood. A note should also be made of a possible mix of species, namely differences in the primary and secondary members;

Determination of wood moisture content. Initially measurements are taken only in specific locations of the structure, where the local conditions suggest the presence of higher moisture content. However, measurements must also be taken in other locations to determine the general equilibrium moisture content of the timber at the time of the inspection.

Determination of environmental conditions. Service Classes defined in EN 1995-1-1 (relevant for mechanical properties) and Use Classes defined in EN 335-2 (related to biological hazard) to which the timber member is exposed must be identified ¹. Note that different parts or members of a timber structure may belong to different hazard classes. If differences between transitory (previous to or during a possible intervention) and target (final) conditions are important, both situations must be identified;

Dendrochronology. This may be carried out to provide additional information on provenance and dating and should be undertaken if the dating of the structure is in doubt and there are adequate large databases for the species and region considered or reliable possibilities of dating by using the reference from the same area but coming from different species (heteroconnection), or by using the references from the same species but coming from different regions (teleconnection).

¹ Service Classes 1 and 2 fit into Use Classes 1 and 2, respectively. Service Class 3 includes Use Classes 3, 4 and 5.

I. 4.3 Defects and damage survey

This should comprise records of:

any areas of biological or fire damage (type/causing agent, location and extension);

type, location and extension of main defects of timber members (specially knots and slope of grain). Since the effect of these defects is reduced considerably when they occur in association with wane, this occurrence must also be reported; since drying fissures follow the grain direction, these hardly affect the load carrying capacity when they are parallel to the beam/column axis. However, drying fissures can be decisive when deviating from this direction. Consequently, when applicable, a fissures pattern drawing must be made;

the location of critical areas² due to biological attack or damage;

any areas of mechanical damage or structural distress in the timbers, such as timber cracks (due to overloading), structural failure of members and joints or excessive deflections (Figure 6);

a note of any distress in supporting structures or members (masonry structures, foundations, etc) and in non load-bearing timber elements that interact with the timber structure;

any timbers missing from the structure (possibly indicated by empty mortises);

a note of any indications of changes made to the structure during its life (Figure 7). These might have been made to accommodate changes in the plan or external form of the building or previous repairs. These often result in changes to the load paths and, consequently, in changed loading at members and connections. When known, these changes must be reported;

any places where timbers could not be clearly seen and where opening up of the structure might be required. Examples are wall plates concealed by roof coverings, timbers behind plasterwork or timber beams built into masonry walls.

I. 5. STRUCTURAL ANALYSIS

The purpose of the structural analysis is to identify highly stressed areas of the structure where more attention is required during the survey. Thus it should identify the critical areas/zones that need special attention and possibly further inspection. It should describe the overall structural system and, where appropriate, determine the stress levels within the structure.

In some cases, a simple and conservative assessment of the structural scheme, of the member properties and their effective cross sections, as well as joint performance, may be sufficient. Alternatively, the preliminary assessment might indicate the need for a more detailed analysis.

In the case of spatial load bearing systems, numerical analysis with 3-dimensional models may be necessary (Figure 8).

The structural analysis of an historic structure is a difficult process with many uncertainties because it is not always possible to estimate the strength and stiffness of structural members and joints, the load history, or the boundary conditions. Neither can one be certain whether elements of the fabric, which were not intended to be structural,

² The definition of a critical area is given under DEFINITIONS.

may nevertheless be carrying load. A common mistake in numerical analysis is to assume that the joints are capable of transferring forces which they cannot in fact. It may also be necessary to allow for members that have become sufficiently decayed that they have shed significant loads to other members. Therefore one may well have to consider more than one load path, possibly reviewing the structure itself to choose between them.

On the other hand, if the mechanical properties of members can be assessed, they frequently exceed the so called characteristic values that would be used in the design of new structures. That is because the 5% exclusion figure, which is used to define the characteristic values, is relatively low compared with the average for the material. Furthermore, when the mechanical properties are assessed successfully, there is need for a partial material factor $\gamma_M > 1,0$. If there is a change of use or some other modification that affects the levels of stress in the members, the analysis should consider the appropriate loads for those changes.

Historic timber structures have generally been more flexible than those designed today but have, nevertheless, performed satisfactorily. It is not, therefore, appropriate to apply modern service limit states, which might result in condemning perfectly adequate structures.

The engineer should assess the overall stability of the structure as well as the behaviour of individual members or individual frames. Therefore the adequacy of braces needs to be considered as well as that of the principal structural members.

Some carpentry joints may be able to transfer moments to some extent, as well as shear and compression loads. Providing that suitable data is available for their moment-rotation capacity, their contribution to the overall structural performance may be taken into account instead of assuming them to be pinned joints.

I. 6. PRELIMINARY REPORT

This report should include:

- dimensioned drawings of the structure completed with technical notes describing the structural system, and its principal features;
- record of problems and pathology, as listed in clause I.4.;
- a note of any timbers and joints that have not been inspected and why;
- structural calculations showing the loads on the structure and the stresses and deformations;
- identification of the different structural member types – according to the type and level of stresses (see Part II below) and the location of critical areas –either from the point of view of the level of stresses or due to the presence of timber defects or biological damage;
- service classes and risk classes;
- interpretation of the causes of damage and general behaviour of the structure (diagnosis); identification of additional survey and assessment work required, fully justifying the need for any recommended work and noting any places where the structure needs to be opened up to enable the survey work to be carried out;
- identification and justification of any specialist equipment that will be required.

PART II - DETAILED SURVEY OF TIMBERS

II. 1. INTRODUCTION

The aim of the detailed survey is to obtain for the timber elements that are specified in the assessment report the following additional information (UNI 1119:2004):

- wood species;
- moisture content values;
- strength grade or strength values to be used in the structural analyses. Since strength grades, listed in standards (e.g. for new designed structures, the strength grades according to EN 338 are used) only provide characteristic values, assessment of the existing structural members into a strength class most probably result in a (very) conservative assessment;
- characterisation of biological damage.

These are particularly important for all critical areas of the structure that have been identified and will enable stress levels to be recalculated to support the final diagnostic report that follows.

II. 2. IDENTIFICATION OF WOOD SPECIES

This may be conducted through visual inspection (see Part I). In some cases, small samples for laboratorial identification of wood species (by microscopic analysis) may be required. The method used should be clearly stated.

Even where historic records provide information on wood species, these should be confirmed.

II. 3. DETERMINATION OF WOOD MOISTURE CONTENT AND MOISTURE GRADIENTS

The measurements should be taken for each element where there is higher risk of biological attack, such as close to the wall supports of floor beams and at roof edges and corners.

In the presence of fungal attack or subterranean termite infestation³, which are closely related to high moisture content of timber, moisture content readings should be taken at several distances from the ends of the element. Measurements should be taken at various depths from the surface of the element by means of appropriate non-destructive methods such as insulated electrodes. The equipment used for that purpose must be calibrated for the specific species or group of species and readings be taken and corrected for the environmental conditions, according to the equipment manufacturer's specifications.

Moisture content measurements will help to determine the local environmental conditions and the biological risk level for each element. This could vary along the same element according to the local environments. This data will also help establish the potential for further progress of biological deterioration and to plan subsequent interventions aimed at reducing the risk.

³ Some wood boring beetles such as *Xestobium rufovillosum* also prefer wet wood.

II. 4. STRENGTH GRADING OF TIMBER

II. 4.1. Principles

Relevant members in critical areas (see Definitions) must be strength graded, or the relevant actual strength properties assessed. This can be based on visual inspection of timber features and defects (visual grading), on non-destructive measurements of one or more physical or mechanical properties, or on an appropriate combination of both methods (UNI 1119:2004).

The ratio between applied stresses and the strength capacity of the timber member (stress level) for the mechanical properties corresponding to the timber quality that is representative of the structure and the effective (residual) cross section representative of most members should be calculated.

For the critical cross sections (where there are high stress levels or higher degradation), the stress levels should be recalculated for the effective cross section and the actual timber grade.

II. 4.2. Basis of the strength grading of historic timbers and research needed

The intention behind any assessment of strength should be the retention of the maximum amount of historic material.

Therefore the first task in assessing historic timbers is to consider their load conditions and to make some assessment of the magnitude of stresses they may be subjected to. This means that the first step is the recognition of the structural system and the use of appropriate structural models. Note that this may be an iterative process. Should one or more timbers prove inadequate for a proposed structural scheme an alternative load path may need to be considered.

The commercial grading of timbers into strength classes is carried out to obtain the maximum yield and for simplicity of specification by engineers. It takes no account of the conditions of use. In contrast, the location and stress conditions of historic timbers are known as are the positions of specific growth characteristics, thus allowing the importance of defects to be evaluated in relation to the applied stresses. As a simple example there is little point in grading a strut, which will only be loaded in compression, for characteristics that can only affect the ability of a member to resist bending. Besides, in members subjected to bending, the size allowance for knots should vary depending on their particular position along the section and along the length of the element.

Current grading rules used for new timber structures are not well suited to historic timbers for a number of reasons.

- i) in current visual grading standards, grades are referred to specific commercial timber sizes, which differ from the typical traditional scantlings and do not properly take into account size effect in old timber (dimensions and conversion process);
- ii) current grading rules make no allowance for the sizes of timbers and methods of conversion which were quite different in the past from current methods;
- iii) the reliability of visual grading rules applied to old timber material and to many species used in the past has not been adequately assessed;

- iv) rules for commercial timber set limits on a number of singularities that are not grade-determining (e.g. distortion), they do not reflect the exact mechanical effect of fissures - that may be quite large in old structures - and are difficult to apply on site when just one or two faces and no ends can be made accessible;
- v) most methods of visual grading derive fifth percentile values of mechanical properties, which may underestimate the true strength of specific beams;
- vi) the existing EN 338 strength classes system has not been devised with historic buildings in mind, where smaller steps between consecutive strength classes and even modified “strength profiles” would be more appropriate.

In spite of these difficulties there is no other guidance until further research has been carried out. Nevertheless, graders should be aware of the limitations listed above.

II. 4. 3. Identification of structural member types

Structural timbers may be divided into the following types:

- i) Members subject to bending in conditions where there is no load sharing, e.g. principal beams in floors and purlins in roofs.
- ii) Members subject to bending where load-sharing is possible, e.g. joists, and common rafters.
- iii) Members subject to direct compression, i.e. struts or posts under axial load only.
- iv) Members in direct compression and bending, e.g. posts subject to wind loads or posts in frames where braces impose bending loads on posts.
- v) Members in tension, e.g. king posts in roof trusses.
- vi) Members in tension and bending, e.g. tie beams of roofs that are also in bending from struts or principal rafters, or carry heavy ceiling loads.

Types i & ii require the same approach to strength assessment.

The most important defects to take into account in grading are knots and slope of grain. Knot clusters in beams have a more severe effect towards areas of high bending moments, while splits and slope of grain are more significant towards the supports where shear forces are highest. Margin knots are the more critical and have a more severe effect on the tension side of a beam. Knots on the compression side are far less significant. However, as stated before, the negative effect of knots and slope of grain is less pronounced when in combination with wane (where no fibres are cut through by a manufacturing process).

Where there is load sharing, an increase of 10%, as indicated in Eurocode 5 ([EN 1995-1-1) should be allowed to the strength of timber members⁴ However in historic buildings it may also be appropriate to allow a member to shed all or part of its load onto adjacent members. This enables a single poor quality or severely damaged member to be retained as long as the adjacent members can carry the additional loads.

The deflection limits specified in modern design codes may not be appropriate for the historic building since, for example, some historic roof structures have a satisfactory

⁴ See EN 1995-1-1, section 6.6: When several equally spaced similar members, components or assemblies are laterally connected by a continuous load distribution system capable of transferring the loads from one member to the neighbouring ones (e.g. planks), the member strength properties may be multiplied by the system strength factor $k_{sys}=1.1$.

performance in spite of large permanent deflections.⁵ Moreover, floor structures are seldom required to carry a permanent loading that is close to the modern design requirements.⁶ These are situations where the requirements of the specific client or public authorities need to be taken into account⁷.

Type iii members do not generally require grading.

Where compression members are large, as in the main posts of timber frames, stresses will be low and the effect of knots will usually be small. Where compression members are small, as in stud walls, knots may well have a serious effect on the stiffness of a member.

However, as such structures are load-sharing systems it may be acceptable for the load on one stud to be shed to adjacent studs. Only when two or more adjacent studs have significant knots need any consideration be given to their grading.

Type iv members generally require an assessment for strength in the vicinity of the brace / maximum moment. Allowance needs to be made for the reduction in section produced by the joint for example of a brace which is likely to be the most critical factor affecting the member load bearing capacity. Assuming pin-ended members the bending moments will reduce to zero at the ends of the member and the assessment of strength should take account of the consequent reduction in stress along the length of the member.

Type v members are generally subject to low tension stresses and will only be critical in area of joints. In this case, fissures are not important for the strength grading of the member, unless they are associated with high slope of grain, even if they are through the full width of the timber.

Type vi members – While the tension stresses are generally low, maximum bending moments may occur close to the ends so that the relaxation in the criteria for knots which applies to beams is not appropriate for these members. Note also that bending and shear forces may well be high at the same position in the member.

In types v and vi members, allowance needs to be made for the reduction in section produced by the joint.

II. 5. ON-SITE VISUAL STRENGTH GRADING OF STRUCTURAL TIMBER MEMBERS

According to the nature, dimension and position of defects, relevant timber element can be visually graded in order to obtain characteristic strength values.

In the absence of the actual strength values for each timber member, it is necessary to obtain characteristic strength values for the timbers so that the structure itself can be assessed according to the principles of EN 1995-1-1. Some countries may have available visual grading rules for establishing the characteristic stresses for the

⁵ This is usually the result of creep because the timbers were loaded while green, the adopted sections are insufficient to comply with modern serviceability limit conditions and/or high moisture was present in the structure at a given time in the past. Besides, lower deflection limits set for modern timber building structures are mainly meant to avoid damaging brittle linings and facades, for the sake of the occupants' comfort and for aesthetics.

⁶ E.g. *Office floor loadings in historic buildings*, English Heritage, 1994 suggests lower office floor loadings than those in the present design code.

⁷ In several cases, the loads deriving from the new use of the historic building have to be reconsidered because they may lead to excessive reinforcements, or even replacement of the original timber structural system.

commonly used species. However other countries may not have visual grading rules and corresponding strength data.

Should this be the case, in the absence of better judgement and bearing in mind that this may be a conservative approach, a method is needed to enable the timber specialist to place the timbers within the strength classes listed in EN 338. The method by which this can be done is to use the grading rules used elsewhere for equivalent timbers. The judgement on equivalence may be based first on species and then on density and modulus of elasticity. Only the grade-determining parameters should be taken into account (disregarding for this purpose the grade limits for distortion, resin pockets, bark, wane and biological attack) and careful judgement is required on the influence of fissures and knots according to the type of member as discussed in II.4.3.

Guidance on the assignment of species, source and visual grades to the strength classes is given in EN 1912. Information on existing grading standards and the species to which they are normally applied is also given in this standard.

In this context in order to assign a grade, it is necessary that all relevant strength determining growth characteristics and/or defects fall within the specified limits for that grade. The assignment of intermediate grades may be made at the engineers discretion when adequately justified. For this purpose, only strength determining features and defects should be considered for the purpose of assigning a grade to the timber member. Knots, slope of grain and density (or rate of growth) are certainly to be considered, whereas distortion may be ignored in all cases⁸. Fissures, wane and biological attack are to be taken into account elsewhere, but don't have to conform with the limits set for visual grades.

Visual grading needs experienced conservators, or properly trained specialists.

The following principles apply (UNI 11119: 2004):

- grade the entire member and, if necessary, identify each critical zone separately;
- if the number of visible sides of the timber member is less than three or if none of the end faces can be observed, this must be explicitly mentioned in the inspection report;
- if some areas are affected by mechanical damage or localised biological attack (fungal or surface insect attack) make it clear that the classification only applies to the undamaged section;
- if some areas are affected by wood boring insect attack which has spread throughout the whole cross section (widespread attack) consider the whole cross section when grading. Possible density loss may have to be considered.

II. 6. STRENGTH ASSESSMENT USING NON-DESTRUCTIVE TECHNIQUES

In some cases, on site visual inspection can be completed by supplementary tests through the use of one or more non-destructive methods with the aim of determining physical and/or mechanical properties which can be clearly correlated with the strength

⁸ Engineers in charge of the structural analysis must pay a special attention to the fact that modern standards (like EN 1995-1-1) report some verification under the hypothesis of a maximum deviation from straightness. When elements exceed this limit, equations reported for the verification of stability of members must be corrected consequently, i.e. "bending stresses due to initial curvature... shall be taken into account", and a second order analysis shall be done. This is particularly significant when dealing with: iii) members subject to direct compression and iv) members in direct compression and bending.

of the critical section itself. Non-destructive tests may also be used to assess globally the structure (e.g. proof-loading, dynamic response).

Whichever methods are used, the tests must have the least possible impact, taking into account the characteristics and historical value of the structure and of the specific timber member under analysis.

Given the uncertainty of the data obtained, when non-destructive testing methods are used, it is always necessary to check the measurements obtained against those obtained by different methods. Whenever possible, in using values supplied by such investigations, one shall consider the margins of error within the data.

II. 7. CHARACTERIZATION OF BIOLOGICAL DAMAGE

II. 7.1. Identification of biological damage

One shall recognize, specify and characterize biological damage (Figures 9 and 10).

Possible correlation between this and environmental conditions must be analysed.

Therefore, particular attention must be given to the analysis of moisture conditions in the vicinity of the wooden member or a part of it (for example, the ends of beams and trusses inserted in walls).

II. 7.2. Assessment of effective cross section

In the presence of fungal attack, the estimation of an effective cross section, which may vary along the length of the element, is normally difficult. Non-destructive techniques (e.g drilling methods) may be used to help establish the mass loss or density loss caused by fungal attack and the effective reduction of timber mechanical properties. The method used must be recorded.

Where decay has penetrated the full cross section the load bearing capacity must be considered to be zero. Less severe situations of decay must be carefully judged and justified.

In the case of subterranean termites, the timbers may exhibit no external signs of attack, even if the element may have important internal degradation. The volume of destructed material must be carefully estimated (e.g. by drilling or other non-destructive methods) in order to judge the corresponding strength loss and needed intervention.

Where insect attack is confined to a well-defined area of the cross section (normally the sapwood of a durable species), the effective (residual) cross section should be reported and used to calculate the load bearing capacity of the timber member (Figure 11).

II. 7.3. Assessment of residual density (or equivalent density loss)

Where insect attack is in a diffuse pattern throughout the section the total cross section could be used with the strength reduced to account for the reduction in average density, if applicable.⁹

An estimation of actual density or an estimation of loss of cross section area should therefore be made.

⁹ Research in the area is ongoing

PART III - DETAILED SURVEY OF TIMBER JOINTS

III. 1. INTRODUCTION

It is important to understand the behaviour of joints and the way in which they transfer loads.

Some traditions of carpentry rely heavily on pegged mortise and tenon joints while other traditions use lap joints. Still others use nailed or bolted joints.

Historic joints may usually be considered as adequate for the loads that they are carrying and will require no detailed assessment except where there has been an increase in the load or when they show obvious deficiencies or damage.

In such cases the stress conditions will depend upon details of the carpentry and close examination of the joints, possibly by drilling, might be required to determine the geometry of the joint and thus which parts are under stress. Note also that the stresses in either the foundation member or the joining member can be critical.

It is important to understand the way in which the joints were made (or should have been made) and the way in which they were intended to perform. The joints may not be performing in that way today because of poor workmanship in the first instance, because of changes that have occurred over time, or because of a combination of the above. Note that joints intended to work in one mode may have been subject to loads and stresses that they were not intended to carry. For example, a joint originally intended to transmit compression loads only may be called upon to carry bending moments as well.

Thus, the actual load conditions of joints should, as far as possible, be considered when assessing their load bearing capacity.

Common conditions to be considered are:

- i) Compression across the grain where the joining member bears on the foundation member. One or both of the members may be loaded across the grain.
- ii) Compression at an angle to the grain in mortise and tenon joints. The critical condition is normally compression on the end of the tenon.
- iii) Shear along the grain. This may be critical where there is short grain towards the end of a member in tension, e.g. behind the mortise or notch which is receiving thrust from a principal rafter at the end of a tie beam.
- iv) Tension across the grain due to fasteners in line restraining timber shrinkage or due to poor joint design and detailing either related to geometry or small end distances.

Where joints are pegged, no allowance should be made for the capacity of the peg, because its stress condition cannot readily be determined. Therefore pegged mortise and tenon joints can only be considered as acting in compression. In pegged lap-dovetail joints it is the bearing of the dovetail that will be carrying any loads in tension. In several cases pegs or metal fasteners were not used for transferring loads but keep the timber parts connected.

III. 2. DETAILED GEOMETRY

The timber specialist should be familiar with the types of joints used in the structure being assessed. The detailed geometry of critical joints should be measured, namely:
timber cross sections

details of the carpentry
diameter and type of metal or wooden fasteners
edge and end distances

NDT methods (e.g. drilling resistance) may be used for the determination of hidden geometrical characteristics of joints (e.g. presence and dimensions of tenons and mortices, gaps).

III. 3. PATHOLOGY

Workmanship needs to be considered in respect of:

- poor fitting of the timbers
- insufficient spacing or end and edge distances of mechanical fasteners
- missing fasteners
- insufficient bearing of beams
- eccentricity of loading

Changes over time may be:

- corrosion of metal fasteners, straps and plates
- shrinkage of timbers and associated fissures
- biological attack
- fire attack
- intentional modifications (human interventions)
- failures, movements (Figure 12), deformations as a result of excessive loading
- crushing of timbers
- buckling of metal fasteners

All such features need to be recorded.

III. 4. TIMBER QUALITY AND CONDITIONS

In many cases the condition of timber at the joints, and hence the capacity of the joint to transmit load, may well be the principal factor determining the forces within a member. The density of the timber is the relevant mechanical property in determining the load carrying capacity of the joint. Non-destructive techniques, e.g. resistance drilling may be a useful tool to obtain information on the density of the timber needed for calculations as well as to clarify the details of construction (existence and geometry of mortises or hidden parts of the joint).

Knots will only decrease the joint strength if they prevent proper insertion of fasteners. However, fissures in the jointing area may seriously affect its load bearing capacity.

Similarly, biological attack of timber at joints is particularly serious since even a surface degradation may have a great impact on the joint performance.

Note that shrinkage of timbers may not only have affected the nature of the joint and its ability to carry load but in some cases may also have changed the overall behaviour of the structure.

ACKNOWLEDGEMENTS

This paper originates from a document with the same name prepared by the Task Group "Assessment of Timber Structures" set within COST Action IE0601 – Wood Science for Conservation of Cultural Heritage (WoodCultHer) and presented to its final

meeting in November 2011. Therefore, the authors thank to COST for sponsoring two Task Group meetings, CIS-Madeira (SP) and LNEC (P) for hosting them and Dr. Philippe Galimard, Dr. Emmanuel Maurin, Dr. Ladislav Reinprecht and Dr. Artur Feio for their suggestions. They also acknowledge the work done by all the Committees working on the same subject in the past, namely ICOMOS/ISCARSAH, CIB/Commission W023, CEN/TC250, ISO/TC98, UNI - CT Normal - GL20 and COST Action E55, which produced the valuable standards, guidelines and other background documents referenced in the text and listed under Bibliography.

FINAL REMARKS

This paper provides information on the criteria to be used in the assessment of load bearing timber structures in heritage buildings. It covers the preliminary assessment (desk survey, preliminary visual survey, measured survey, structural analysis and preliminary report), as well as the detailed survey of timbers (with a special emphasis on visual strength grading on site) and carpentry joints.

The subsequent diagnostic report and the detailed design of repairs, which are also fundamental tools for a safe, sound and respectful intervention, are however outside its scope.

DEFINITIONS

Alteration – Any kind of modification to wood (biological, mechanical, chemical) or to metallic materials occurring after their installation.

Action – Any agent (forces, deformations, etc.) which directly or indirectly produces stresses and/or strains into a building structure and any phenomenon (chemical, biological, etc.) which affects the materials which compose it.

Critical area/zone – A part of a timber element over a length of 150mm, or equal to the depth of the member, whichever is the greater, which is considered to be relevant to the performance of the structure because of defects, position, state of preservation and also stress conditions as determined by static analysis (UNI 11119: 2004).

Critical cross section – The cross section which is representative of a critical zone. All the defects, alterations, damage and other characteristics that are present in the critical zone and have an influence on its strength are attributed to the critical section (UNI 11119: 2004).

Decay – Change and worsening of the materials' characteristics produced by fungi (EN1001-2).

Defects (of wood) – Wood growth features which can negatively influence strength and stiffness, and/or the general structural behaviour (e.g. the efficiency of joints) of timber members.

Diagnosis – The act or process of identifying or determining the nature and cause of damage and/or biological attack through observation, investigation (including mathematical models) and historical analysis, and the opinion derived from such activities.

Effective cross section – The part of the cross section of a timber member which is assumed to carry the load.

Holistic – Emphasizing the importance of the whole and the interdependence of its parts.

Inspection – On-site non-destructive examination to establish the present condition of the structure.

Load testing (proof-loading) – Test of the structure or part thereof by loading to evaluate its behaviour or properties, or to predict its load-bearing capacity.

Mechanical damage – Alteration of timber members or timber structures which appears as mechanical failures, caused by internal or external mechanical actions.

Non destructive test – A test that has a minor impact on the timber member and that does not influence its load bearing capacity.

Safety evaluation (assessment) – Evaluation of the safety margins of a structure.

State of preservation – State of a timber member in relation to alterations that are present.

Strength grading – A procedure through which a single timber member can be allocated to a grade which corresponds to a known level of mechanical performance.

REFERENCES¹⁰

EN 335-2 – Durability of wood and wood-based products – Definition of use classes – Part 2: Application to solid wood.

EN 338 – Structural timber - Strength classes.

EN1001-2 Durability of wood and wood based products —Terminology —Part 2: Vocabulary

EN 1990 – Eurocode: Basis of structural design.

EN 1912 – Structural timber - Strength classes - Assignment of visual grades and species.

EN 1995-1-1 – Eurocode 5: Design of timber structures - Part 1-1: General - Common rules and rules for buildings.

UNI 11119 (English version: 2004) – Cultural Heritage - Wooden artefacts -Load-bearing structures. On-site inspections for the diagnosis of timber members.

BIBLIOGRAPHY

Assessment of timber structures (2010) - Task Group Report within COST Action E55 (Modelling of the performance of timber structures). Ed. Phillip Dietsch and Jochen Kohler. Shaker Verlag GmbH.

CIB Publication 335 (2010) – Guide for the Structural rehabilitation of Heritage buildings. International Council for Research and Innovation in Building and Construction / Commission W023

ICOMOS (1999) – Principles for the preservation of historic timber structures

ICOMOS/ISCARSAH Charter (2003) – Principles for the analysis, conservation and structural restoration of architectural heritage. Ratified by the ICOMOS 14th General Assembly in Victoria Falls, Zimbabwe, in 2003

ICOMOS/ISCARSAH Guidelines (2005). Recommendations for the analysis, conservation and structural restoration of architectural heritage.

ISO 13822 (2010) – Bases for design of structures – Assessment of existing structures.

UNI 11118 (English version: 2004) – Cultural heritage - Wooden artefacts - Criteria for the identification of the wood species.

UNI 11138 (English version: 2004) – Cultural heritage - Wooden artefacts - Building load bearing structures - Criteria for the preliminary evaluation, the design and the execution of works.

UNI 11161 (English version: 2005) – Cultural heritage - Wooden artefacts - Guideline for conservation, restoration and maintenance

¹⁰ The latest version of the referred standards should be followed.




Figure 1 – Steps required for the assessment and planning of interventions in historic timber structures



Figure 2 - Need for propping




Figure 3 - Dimensioned survey of a timber floor. VP, PM: main beams; VS: Secondary beam (dimensions in metres)




Figure 4 – Examples of axonometric drawings of the structural system and construction details



Figure 5 - Spatial structure of high complexity



Figure 6 - Timber failure in the vicinity of the joint



Figure 7 - Missing part of the structure due to previous interventions




Figure 8 - 3-D model of the timber roof structure



Figure 9 - Subterranean termites attack



Figure 10 - Fungal attack




Figure 11 – Possible idealization of residual cross section (“equivalent” sound cross section)



Figure 12 - Lack of contact and failure of the joint